DANCOVER[®]

PARTY TENT 5m PE series

DANCOVER

.com

Safety Advice

Attention

In some countries approval is needed to set up a tent larger than 75 m2.

The owner of the tent has the sole responsibility to make sure that these local rules are followed and that the mounting is correct.

In case of bad weather conditions, it is your responsibility to ensure that people inside are safe and that the tent does not cause damage to others.

Do not use open fire, welding equipment or other ignition sources in the tent. Though the fabric is made of flame retardant material it can still burn.

It is always recommended that you secure your tent properly with safety straps and augers when you put up the structure.

We recommend you to insure the tent, or check if it is covered by home contents insurance, in case of unplanned events, accidents or bad weather.

Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.

This structure is not tested for specific snow and wind loads. That's why we always recommend to remove snow from the top.

5m PE series Instruction						
Part no.			5x6m	5x8m	5x10m	5X12M
1	Frame pole	0)	8	10	12	14
2	Frame pole	0)	17	22	27	32
4	Leg	G	8	10	12	14
5	2-way connector	00	8	10	12	14
6	110° 3-way Connector		4	4	4	4
7	110° 4-way Connector		4	6	8	10
8	140° 3-way Connector		2	2	2	2
9	140° 4-way Connector		2	3	4	5
10	Spiral peg		4	4	4	4
11	Middle peg		8	10	12	14
12	Small peg		32	36	40	44
13	Screw		58	74	90	106
14	Bungeeball long		70	78	86	94
15	Bungeeball short	\mathcal{O}	22	22	22	22
16	Rope		4	4	4	4
18	Roof	En mart	1	1	1	1
19	Sidewall		2	2	2	2
20	Endwall		2	2	2	2


15-01-2013

Assemble Manual




Select a flat ground for the tent, unpack the carton and check all the parts including tubes, tent and accessories... etc. are present as same as list.

Assemble the framework of rooftop by joining the portion (5.6.7.8.9.) together with poles (1.2.4).






Attach one end of supported pole (4) to the joints (6.7)




Step 3


Cover the roof on the frame ,and attach it by the bungee balls properly ,take care of the tension of the bungee balls ,for if you use too many on one side of tent ,it may too tight to tie the other side.



Step 4

Attach the other supported poles to the joints, built-up the framework, use the long peg to fix each pole into the ground and attach the leg cover to the sidewall by velcro.





- 1. In order to avoid rust on the pipes, oil is covered on the surface. Before you set up the tent, please remove the oil carefully to keep the cover clean.
- 2. Take note that the tent needs to be handled carefully to avoid damage.
- 3. Do not force the frame as it may be damaged in the process.
- 4. Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.
- 5. The windows may stick to each other, when you unfold it. Please do as softly as you can, or the windows may crack during the process.

Please select a suitable site for the tent to avoid damage to underground sprinkler systems, water, gas or electrical lines.

DANCOVER[®]

Contact information

Head office:

Dancover A/S Nordre Strandvej 119 G 3150 Hellebæk Denmark For more information please visit: www.dancovershop.com

National contact

Denmark: denmark@dancover.com

UK: uk@dancover.com

Germany: germany@dancover.com

France: france@dancover.com

Sweden: sverige@dancover.com

Finland: suomi@dancover.com

Poland: polska@dancover.com

Luxembourg: luxembourg@dancover.com Spain: espana@dancover.com

Italy: italia@dancover.com

Switzerland: schweiz@dancover.com

Austria: austria@dancover.com

Norway: norge@dancover.com

Nederland: nederland@dancover.com

Ireland: ireland@dancover.com

Belgium: belgique@dancover.com